

ASSEMBLY AND INSTALLATION INSTRUCTIONS

All dimensions in millimetres

<p>Required space</p>	<p>Tipmatic Pin</p>
<p>Side wall milling position</p> <p>● Countersunk screw 3.5 x 13 mm</p>	<p>Front milling position</p> <p>● Countersunk screw 3.5 x 13 mm</p>
<p>Calculation of power factor (LF) Flap height (mm) x {flap weight (kg) + 2 x handle weight (kg)}</p>	

CORNICE

REVEAL


FLAP WEIGHT

Flap thickness (KLS)	Cabinet top panel (KOB)					
	16	18	19	20	22	24
16	67	74	77	80	87	94
18	60	67	70	73	80	87
19	57	64	67	70	77	84
20	54	60	63	67	73	80
21	50	56	60	63	69	76
22	47	53	57	60	66	73
24	40	46	50	53	60	67
26	33	40	43	46	53	60
32	12	19	22	25	32	38
Cornice (KP)						

Flap thickness (KLS)	Front overlay, top (FAO)				
	15	17	19	21	22
16	1	1	1	1	1
18	1	1	1	1	1
19	1	1	1	1	1
20	1	1	1	1	1
21	1	1	1	1	1
22	1	1	1	1	1
24	1.5	1	1	1	1
26	3	2.5	1.5	1	1
32	8	7	6	5.5	5
Reveal (F)					

Flap height (KLH)	Power factor (LF)	
	1500-3375	
200	7.5-16.9	
250	6.0-13.5	
300	5.0-11.3	
350	4.3-9.6	
400	3.8-8.4	
450	3.3-7.5	
500	3.0-6.8	
550	2.7-6.1	
Flap weight in kg		

WARNING



Important!
Caution – risk of injury!
Fitting is spring-tensioned!

LEGEND

- F Reveal
- FAO Front overlay, top
- FAS Front overlay, side
- FH Front height
- KB Cabinet width
- KLS Flap thickness
- KOB Cabinet top panel
- KP Cornice
- LF Power factor

