

KINVARO

F-20 folding flap fitting

ASSEMBLY AND INSTALLATION INSTRUCTIONS FOR CABINET HEIGHT 800-900

All dimensions in millimetres

Required space	Side wall drilling positions	Side wall drilling distance																	
		<table border="1"> <thead> <tr> <th>KH</th> <th>Type</th> <th>B</th> </tr> </thead> <tbody> <tr> <td>800-849</td> <td>7</td> <td>103</td> </tr> <tr> <td>850-900</td> <td>7</td> <td>110</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="2">Shelf distance</th> </tr> <tr> <th>KH</th> <th>D</th> </tr> </thead> <tbody> <tr> <td>800-849</td> <td>≤293</td> </tr> <tr> <td>850-900</td> <td>≤312</td> </tr> </tbody> </table>	KH	Type	B	800-849	7	103	850-900	7	110	Shelf distance		KH	D	800-849	≤293	850-900	≤312
KH	Type	B																	
800-849	7	103																	
850-900	7	110																	
Shelf distance																			
KH	D																		
800-849	≤293																		
850-900	≤312																		
<p>Front installation for flaps with standard aluminium frame profiles (19 mm)</p>	<p>Front installation for wooden and frame flaps (min. 45 mm width)</p>	<p>Front drilling distance</p>																	
<p>* Pre-drilling required Ø 2 mm</p>	<p>* Pre-drilling required Ø 2 mm</p>	<table border="1"> <thead> <tr> <th>KH</th> <th>Type</th> <th>C</th> </tr> </thead> <tbody> <tr> <td>800-900</td> <td>7</td> <td>304</td> </tr> </tbody> </table>	KH	Type	C	800-900	7	304											
KH	Type	C																	
800-900	7	304																	
	<p>Number of hinges on top panel From 900 mm cabinet width: 3 hinges. Hinges with spring require an opening angle of min. 120°</p>																		
<p>Calculation of flap weight Flap width x flap height x flap thickness x density ¹ + weight of handle ² = weight of flap ¹ Densities: MDF board 0.85 kg/dm³, chipboard 0.65 kg/dm³, spruce/pine 0.45 kg/dm³ ² For bar handles, allow 0.1 kg per 100 mm of handle length. We recommend a trial fitting</p>																			

Kinvaro F-20 adjustment options	284
Assembly aids	656