

REMOVER 16 SPRAY

- Colourless synthetic solvent
- Ideal for cleaning guns and hoses of Frencken spray adhesive canisters
- Ready to use

PRODUCT

Remover 16 Spray is a universal cleaner and colourless synthetic solvent and thinner

COMPOSITION AND PROPERTIES

Base	: Solvent mixture
Specific weight	: 0.80 kg/dm ³
Viscosity	: Liquid
Application temperature	: +5°C to +35°C
Colour	: Transparent
Odour	: Solvents
Number of components	: 1

USE

Remover 16 Spray is packaged in a convenient spray can with a practical threaded coupling and is suitable for a variety of applications:

- In combination with the **Frencken Cleaning Adapter**, it is ideal for cleaning the guns and hoses of Frencken spray adhesive canisters (**CS 1428 Fine Fix Spray**, **CS1661 High Tack Spray** and **CS 1212 Classic Spray**).
- Cleaning glue brushes and spatulas, guns and other tools
- Removing excess glue, glue spots and glue strands
- Loosening glue-bonded joints
- Cleaning and degreasing surfaces before bonding
- Ideal for degreasing teak before gluing
- Cleaning nozzles of glue guns
- Cleaning plugged hoses

Caution: Do not use on synthetic materials, paints, varnishes or polystyrene.

APPLICATION

Cleaning or degreasing

Place the nozzle on the valve. Hold the can with the nozzle pointing in the desired spray direction. Press the nozzle with your finger. Allow the product to work in briefly, then remove with a dry cloth or spatula. Remove the red nozzle from the valve after use.

Cleaning glue gun nozzles

Clean glue gun nozzles with a soft brush and Frencken Remover 16 Spray.

Cleaning the gun and hose of a spray adhesive canister

1. Close the canister valve and pull the gun trigger to release the pressure in the hose.
2. Detach the hose.
3. Screw the adapter onto the hose.
4. Screw the Remover 16 Spray can onto the adapter.
5. Pull the gun trigger and spray until a clear liquid emerges.
 - If nothing emerges (gun and/or pistol clogged), allow Frencken Remover 16 Spray to work in.
 - Repeat the spray attempts several times until the glue is dissolved and the pistol sprays properly.
6. Unscrew the Remover 16 Spray can.
7. Empty the gun and hose by spraying.
8. Unscrew the adapter.
9. Reconnect the gun and hose to the canister.

ENVIRONMENTAL APECTS

Due to the composition of the product, there are restrictions on storage, handling and application.

For detailed information, please request a Material Safety Data Sheet (MSDS).

STORAGE, SHELF LIFE AND TRANSPORT

Remover 16 Spray has a shelf life of 24 months in the original unopened container and should be stored in a cool and frost-free place. Transport during freezing weather is possible as long as the product temperature remains above 0°C. Dispose of leftover material and cleaning water at the local or municipal depot for household chemical waste.

EXPIRY DATE ON PACKAGING

A seven-digit code is marked on the packaging. It indicates the expiry date (best before date) as follows:

Example: BB1603001
16 = 2016 (year);
03 = March (month);
001 = internal code

PACKAGING

Packaging	Item number	Package quantity
Spray can 500 ml	70216	6

