

# LEIMPORT

## NO MORE DRIED-OUT GLUE BOTTLES

### Preparation before first use



**Step 1:** Have a glue bottle (500 ml) ready.



**Step 2:** Shorten the spout to the required length and remove the sealing cap.



**Step 3:** Fill the climate control container with 150 ml of water. It is sufficient to check the water level every three months.



**Step 4:** Push the foam inlay slowly into the plastic container until the water has been absorbed completely. Take care that the slit foam inlay is aligned towards the membrane spout.



**Step 5:** Put the climate control container into the non-slip stainless steel stand.



**Step 6:** Fill the bottle with wood glue and insert it into the stainless steel stand as well. The opening of the membrane spout closes automatically when taking out the glue bottle so that the climate is kept humid for a long time.

### Care information

If necessary, all components of the GluePort can be soaked in water and afterwards be cleaned without further effort. Slightly dried-out glue tips will open up again when correctly inserted into the glue holder for a longer period of time.

### Tip

When the elasticity of the foam inlay diminishes, it can be re-slit or rotated several times for an extended use.