


Trowel coverage












In the table below, you can find an overview of the most used trowels, their specifications, an image of how the trowel looks like and the amount of product needed per square metre.











- a** length in mm between 2 spacings in the trowel
- b** width of the spacings
- c** height of the spacings



In addition, the position of the trowel must be considered. When spreading the adhesive, the trowel should be held in a 60° angle.

Trowel	a (mm)	b (mm)	c (mm)	Image of trowel	Coverage
A1	0.5	1.5	1.1		0.357 L/m ²
A2	1.2	1.8	1.5		0.390 L/m ²
A3	0.5	1.5	1.5		0.487 L/m ²
A4	0.5	1	0.7		0.202 L/m ²
A5	1.6	1.3	1		0.194 L/m ²
B1	2.7	2.3	2		0.398 L/m ²
B2	2.1	2.9	2.6		0.653 L/m ²
B3	3.4	3.6	3.2		0.713 L/m ²
B11	8	6	5		0.928 L/m ²
B15	7	5.5	6.5		1.238 L/m ²
B17	4	6.5	9.8		2.627 L/m ²

C1	4	4	4		1.732 L/m ²
C2	6	6	6		2.598 L/m ²
C3	3	3	3		1.299 L/m ²
C4	8	8	8		3.464 L/m ²
S1	0	1.8	2.8		1.212 L/m ²
S2	0	4.2	3.4		1.472 L/m ²
R1	2	4	3		1.732 L/m ²
R2	2	4	5		2.887 L/m ²